

## Adapteri BNT, TNT, LEMO



RejtingJoš uvek neocenjen

**Cena**

[Postavite pitanje o ovom proizvodu](#)

Opis

RTI provides a range of adapter cables. These enable you to connect many different types of ionization chambers.

### **BNT**

BNT (or BNC Triaxial) adapter cable for connection of ion chambers to the RTI Chamber Adapter. Converts from bayonet triaxial connector to LEMO triaxial connector.

### **TNT**

TNT (or TNC Triaxial) adapter cable for connection of ion chambers to the RTI Chamber Adapter. Converts from thread triaxial connector to LEMO triaxial connector.

### **LEMO**

An 8 m high flexible extension cable with LEMO triax connectors to extend the possible distance between your instrument and your ion chamber.

### **Komentari**

Trenutno nema komentara za ovaj proizvod.